www.AdvancedQA.com Info@AdvancedQA.com 6325 Emerson Avenue Parkersburg, WV 26104 (800) 283-4844 (304) 485-6325

## SAMPLE PREPARATION INSTRUCTIONS

BENCHMARK PERFORMANCE AUDIT
WATER SUPPLY (WS) SERIES

Please follow these guidelines for preparing your sample. Proper sample preparation along with appropriate QC methods will allow the greatest chance for assay success. All samples should be mixed well before use and stored at 4°C upon dilution.

## Solids:

Shake the sample well. This sample is whole volume. It is therefore ready to use upon arrival. Analyze it the same as any other sample.